



CITY OF CHICO, CA-FALSE ALARM PREVENTION TIPS

False Alarm Reduction Program
PO Box 888492
Los Angeles, CA 90088-8492

Telephone: (855) 905-0609

Email: chicoca@alarm-billing.com



What is a false alarm?

The City of Chico's Alarm Ordinance defines a false alarm as: *"the notification to the Chico Police Department or concerning the activation of an alarm system or alarm device when there is no evidence of a crime or other activity that warrants the assistance of the Chico Police Department on the premises, as indicated by the investigation of a police officer on the scene or by the lack of a police report filed by the property owner, and no individual who was on or near the premises or who had viewed a video communication from the premises, called for the dispatch or confirmed a need for police response; or the dispatch of police was cancelled by the alarm system monitoring company after the arrival of police at the premises."*

Did you know?

Three main causes of false alarms are: 1) user error, 2) installation/service errors, and 3) equipment failure.

- More than 80 percent of all false alarms are caused by user error
- There are easy steps you and your alarm dealer can take to prevent false alarms
- False alarms present a serious threat to the effectiveness of our local police, fire and EMS departments, as well as to the safety of our citizens
- False alarms are costly and dangerous because they divert police officers from proactive crime prevention efforts and can divert public safety responses from true emergency calls

Major causes of false alarms:

- Unlocked or loose doors/ windows
- Children, Neighbors, and Visitors
- Cleaning Crews/ Repairmen/ Pet Sitters
- Pets or other wildlife
- User Error
- Equipment Malfunction

Before you activate your alarm system:

- Are you and others who use the security system fully educated on its proper operation? This may include domestic/cleaning crews, children, neighbors, caretakers, employees and temporary staff.
- Make sure you securely close and lock all protected doors and windows.
- When leaving your home or business make sure the door you leave through is closed tight.
- Keep pets, balloons, fans, heaters, etc. away from motion sensor areas.
- Know and rehearse the process to cancel an accidental alarm. Anyone with your key should know this process.
- Know how much time you have after you arm your system to leave and to disarm your system when you enter.

Know what to do if you set your alarm off accidentally:

- First, don't panic. Carefully enter your disarm code to reset your system.
- Wait for your Alarm Company or central monitoring station to call, give your password or ID card number.

- **Do not leave your home or business until you have talked with your monitoring station!** If they do not call you, have the number posted by your control panel and contact them to cancel the police dispatch.
- You can arrange to have your alarm monitoring station call you or another designated person first before the police are called whenever your alarm is activated.
- If you are aware of a problem with the system, you can cancel the police dispatch.

At home:

DO NOT call 911 to cancel alarm activations--you must call your monitoring station.

Avoid objects that trigger your alarm:

- Unlocked, loose fitting, or open doors or windows. Always keep doors and windows locked when the alarm is in an "ON" mode to reduce the chance that friends, neighbors or customers enter and cause the alarm to activate.
- Unsupervised pets - If you have pets, take special care to purchase an alarm system that is tolerant of pets. You may not want to purchase motion detectors if your pets have free run of the house when the alarm is on. Also, sometimes barking dogs can activate glass break detectors.
- Balloons- that move can cause motion sensors to go off.
- **DO NOT** call 911 to cancel alarm activations--you must call your alarm company.
- Drafts that move plants and curtains.

At your business:

Watch for these pitfalls that may activate your alarm:

- Swinging doors or windows
- Banners or signs
- Mylar balloons
- Plants or curtains caught in drafts
- Stacked items, such as boxes, which may fall, setting off motion detectors
- Unsupervised guests
- Untrained, unaware or uncaring employees
- Alarm equipment, such as motion sensors or overhead door magnets, being hit by forklifts

Contact your alarm company:

- If you plan any improvement or renovation projects, such as changing phone systems, reconfiguring a room, adding a wall, rearranging cubicles, installing skylights or ceiling fans, or even fumigating.
- If you plan to change your alarm system batteries. This can cause an interruption in your system's power supply which may trigger an alarm activation.
- Also alert your alarm company if you hire domestic help or acquire a pet.

Review with your alarm company the procedures you expect them to follow when your alarm activates:

- Do you want them to attempt to call more than one person on your contact list before requesting emergency dispatch?
- Do you only want the police notified if exterior and interior zones are both activated?
- Put your instructions in writing.

With people:

Enhance your alarm system's potential:

- Train responders with keys on complete system operation.

- Ensure that anyone authorized to use your alarm system is properly trained in its usage.
- Use dead bolt locks.

False alarms:

- Divert emergency resources away from true emergencies.
- Are a nuisance to you and your neighbors.
- Make your security system less reliable.
- Costs you and your community money.

Recommendations:

- Have a maintenance contract with a licensed alarm company and have your alarm system checked every year.
- If you are apprehensive about using your system, call your alarm company TODAY!
- Do your part to prevent false alarms.